



Install genie on bracket

2. Run wire through playfield back left side of genie

3. Twist bulb goes to (JACKPOT) insert in front of genie

4. The fireball works either way but eyes only work powered one way.

so if fireball is lit and eyes are not rotate bulb socket 180 degrees.

5. twist bulb should be on board. red wire toward white connector. see pic.



Thank you for your purchase, feel free to contact us with questions www.pinballpro.com