

Installation Instructions for Uncle Lester

Remove the playfield glass. Remove the Yellow (left) and Red light bulbs from the electric chair. Carefully pull up on the chair to remove it from the bracket. Lay Uncle Lester face down in front of the chair and connect his wires to the left lamp socket. If you can solder, solder the red wire to the top lead and the black striped wire to the bottom lead. If you cannot solder, Strip some more insulation from the leads (half inch or so) and carefully wrap the wires around the lamp leads and cover with some electrical tape cut into thin strips. Make good contact with the wires and cover them well with tape. Route the excess wire as a loop through the hole in the bracket out the back. Replace the electric chair taking care not to hang up on the lamp sockets. Replace the yellow and red bulbs. Pick up Uncle Lester and insert him in the chair by pinching his waist with your left hand fingers and push him back with the right hand fingers on his lap. A little wiggle will seat him firmly in the chair. Pull the excess wire loop out the back and push the loop into the playfield hole with the other wires. If Uncle Lester does not light for some reason, a connection may be loose or reversed. You will not hurt Uncle Lester with reverse voltage but he will not light. Replace the playfield glass and play a game!

